



INOVA Microlight & Microlight XT Instructions

IMPORTANT!

**YOUR INOVA MICROLIGHT HAS BEEN
FACTORY SET IN SIGNAL MODE.**

**TO ACTIVATE YOUR MICROLIGHT
FOR THE FIRST TIME:
PRESS AND HOLD DOWN THE BUTTON
FOR 15 SECONDS UNTIL THE LIGHT GOES OUT.**

OPERATION GUIDE.

Press the button one time for **high power**
Press the button two times for **low power**
Press the button three times for **strobe**

If you leave your Microlight on any setting for more than 2 seconds the next press of the button will turn it off and not go to the next function.

To reset your Microlight into **signal** mode: Press the button three times for strobe mode. While the light is strobing, press and hold the button for 5 seconds. In **signal** mode your light will only work as a squeeze light. To activate normal operating modes press and hold down the button for 15 seconds until the light goes out.

BATTERY REPLACEMENT:

Your **RED / GREEN / BLUE / WHITE** Microlight requires **two** 2016 lithium batteries.

